



PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY
1	Recoil Pad Screw	2	20	Safety Spring	1	39	Scope Base	1
2	Recoil Pad	1	21	Pistol Grip	1	40	Scope Base Screw	6
3	Buttplate Back Screw	2	22	Pistol Grip Stock Washer	1	41	Barrel	1
4	Buttplate	1	23	Pistol Grip Screw	1	42	Muzzle Brake Shim Kit	1
5	Buttplate Front Screw	1	24	Firing Pin Lock Screw	1	43	Muzzle Brake	1
6	Bolt Guide	1	25	Cocking Piece	1	44	Muzzle Brake Screw	1
7	Receiver	1	26	Cocking Piece Shroud	1	45	Barrel Washer	1
8	Sear Pivot Pin	1	27	Firing Pin Spring	1	46	Barrel Nut	1
9	Safety	1	28	Firing Pin	1	47	Bipod Pin	1
10	Sear Pivot	1	29	Bolt	1	48	Yoke Mount Pin	2
11	Sear Pivot Spring	1	30	CP .093 x .625	1	49	Bipod Yoke Mount	2
12	Sear Link	1	31	Bolt Handle	1	50	Bipod Screw	2
13	Sear Link Pin	1	32	Ejector Pin	1	51	Bipod Yoke	1
14	Trigger Overtravel Screw	2	33	Ejector Spring	1	52	Bipod Spring	2
15	Trigger Spring	1	34	Extractor Spring	1	53	Bipod Detent	2
16	Trigger	1	35	Ejector	1	54	Bipod Pin	2
17	Trigger Housing	1	36	Extractor	1	55	Bipod Leg Housing	2
18	Trigger Housing Pin	1	37	Detent Pin	3			
19	Safety Detent	1	38	Barrel Extension	1			